

# 8 Track Smart Chaser Light Controller Settings Instructions| Model 8TSC-18

**Note: All settings should be applied with the controller unplugged.** Please read the General Lighting Controller Instructions before you plug in any controller. Remove the screw and the front panel. The dip switches are adjustable with a small screwdriver or your finger. Gently slide the switches so they correspond with your desired setting. The chart below shows all the available settings for this model. Animated examples for all these settings can be seen at Animated Examples for the 8 Track Smart Chaser. Please call us if you have any questions. (636) 391-1161



## Version 1

Pattern	2 Track	3 Track	4 Track	5 Track	6 Track	7 Track	8 Track
Negative Chase	01000100	01100100	10000100	10100100	11000100	11100100	00000100
Back and Forth	01001000	01101000	10001000	10101000	11001000	11101000	00001000
Speller	01001100	01101100	10001100	10101100	11001100	11101100	00001100
Chase Delay on 1	01010000	01110000	10010000	10110000	11010000	11110000	00010000
Chase Delay on 1 and Last	01010100	01110100	10010100	10110100	11010100	11110100	00010100
Build Up and Down	01011000	01111000	10011000	10111000	11011000	11111000	00011000
Build up	01011100	01111100	10011100	10111100	11011100	11111100	00011100
Chase	01000000	01100000	10000000	10100000	11000000	11100000	00000000
Multi Sequence	-	01110010	10010010	10110010	11010010	11110010	00010010

## Version 2

Pattern	2 Track	3 Track	4 Track	5 Track	6 Track	7 Track	8 Track
Negative Chase	01000000	01100000	10000110	10100110	11000110	11100110	00000110
Back and Forth	01001010	01101010	10001010	10101010	11001010	11101010	00001010
Speller	-	-	-	-	-	-	-
Chase Delay on 1	01010011	01110011	10010011	10110011	11010011	11110011	00010011
Chase Delay on 1 and Last	01010110	01110110	10010110	10110110	11010110	11110110	00010110
Build Up and Down	-	-	-	-	-	-	-
Build up	-	-	-	-	-	-	-
Chase	01000010	01100010	10000010	10100010	11000010	11100010	00000010
Multi Sequence	-	-	-	-	-	-	-

### Special Pre-Programmed Patterns

Present Throw 01100001	Cannon with 2 Arms 11100001	Tennis with 2 Arms 10100001
Bowling with 7 Balls 00000001	Cannon with 3 Arms 00111110	Tennis with 3 Arms 11000001
Snowball Fight 10000001	Golf Version 1 01000001	Fishing with 3 Poles 01000011
Baseball with 6 Balls 00100001	Golf Version 2 11000011	ALL ON 00000011